STARTER REMOVAL & INSTALLATION

1988 Jeep Cherokee

1988 Starters REMOVAL

All Jeep Models

REMOVAL & INSTALLATION

JEEP

Disconnect battery ground cable. Remove electrical wiring from starter or solenoid (Bosch). Remove starter mounting bolts. Remove starter and bracket from bellhousing. To install, reverse removal procedure. Tighten to specifications.

TORQUE SPECIFICATIONS

| TORQUE SPECIFICATIONS TABLE | | | | |
|-----------------------------|-----|-----|-----|-------|
| Application | Ft. | Lbs | S . | (N.m) |
| Jeep | | | 37 | (50) |