

# CHRYSLER CORPORATION

## SERVICE MANUAL and SUPPLEMENT

1994 JEEP®

To order the special service tools used and illustrated, please refer to the instructions on inside back cover.



NO PART OF THIS PUBLICATION MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM, OR TRANSMITTED, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING, OR OTHERWISE, WITHOUT THE PRIOR WRITTEN PERMISSION OF CHRYSLER CORPORATION.

Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

Litho in U.S.A. Copyright © 1993 Chrysler Corporation 20M0693

**NEXT PAGE** ►

## FOREWORD

The information contained in this service manual has been prepared for the professional automotive technician involved in daily repair operations. This manual does not cover theory of operation, which is addressed in service training material. Information describing the operation and use of standard and optional equipment is included in the Owner's Manual provided with the vehicle.

Information in this manual is divided into groups. These groups contain general information, diagnosis, testing, adjustments, removal, installation, disassembly, and assembly procedures for the components. To assist in locating a group title page, use the Group Tab Locator on the following page. The solid bar after the group title is aligned to a solid tab on the first page of each group. The first page of the group has a contents section that lists major topics within the group. If you are not sure which Group contains the information you need, look up the Component/System in the alphabetical index located in the rear of this manual.

A Service Manual Comment form is included at the rear of this manual. Use the form to provide Chrysler Corporation with your comments and suggestions.

Tightening torques are provided as a specific value throughout this manual. This value represents the midpoint of the acceptable engineering torque range for a given fastener application. These torque values are intended for use in service assembly and installation procedures using the correct OEM fasteners. When replacing fasteners, always use the same type (part number) fastener as removed.

Chrysler Corporation reserves the right to change testing procedures, specifications, diagnosis, repair methods, or vehicle wiring at any time without prior notice or incurring obligation.

**NOTE:** The acronyms, terminology and nomenclature used to identify emissions related components in this manual may have changed from prior publications. These new terms are in compliance with S.A.E. recommended practice J1930.

## GROUP TAB LOCATOR PAGE

NOTE: Groups with the suffix “-S” are supplements to the original service manual publication.

IN	Introduction	
0	Lubrication and Maintenance	
2	Front Suspension and Axle	
3	Rear Suspension and Axles	
5	Brakes	
6	Clutch	
7	Cooling System	
8	Electrical	
9	Engines	
11	Exhaust System and Intake Manifold	
13	Frame and Bumpers	
14	Fuel System	
16	Propeller Shafts	
19	Steering	
21	Transmissions and Transfer Cases	
22	Wheels and Tires	
23	Body Components	
24	Heating and Air Conditioning	
24-S	Air Conditioning	
25	Emission Control Systems	
	Index	
	Index Supplement	
	Service Manual Comment Forms	(Rear of Manual)

